

THE Best VALUE UNDERFOOT

PATTERN TEMPLATE INSTRUCTIONS

- 1. Firmly press paper down into the desired mat area. Run your hand around the mat outline to make the paper fit into the floor pan.
- 2. With the paper still in the vehicle, trace the mat shape on the paper with a pencil.
- 3. Remove the paper from the vehicle and cut around your outline.
- 4. Place your paper back into the mat area of the vehicle to test the size. If it's too big, repeat steps 2 and 3. If it's too small, tape scrap paper to the edge of your mat mat template and repeat steps above until you have the correct fit.
- 5. Repeat this process for all front and rear mats.
- 6. Mark the pattern with your name, phone number, email address and car information (year, make, model). Then mark which end is the top (under the pedals) of your mat, along with which side is the carpet side. This ensures that your mat will be oriented the proper way.
- 7. Mail your pattern template to:

QUALITY CAR MATS ATTN: CUSTOMER SERVICE 506 MARTHA SUE DRIVE DALTON, GA 30721





